

Walk Safe with Walk the Walk's personal alarm!

Walk the Walk takes the safety of our Walkers very seriously and have therefore tested the market and in our opinion this is the best personal alarm that we have found. The personal attack alarm with electronic sensor is small and discrete and perfectly shaped to fit comfortably in your hand whilst walking.

Statistics show that a large percentage of assaults by opportunistic aggressors are undertaken by attacking the victim from behind, giving the victim little or no opportunity to activate a conventional personal alarm. However provided the sensor is on the C setting, in the event of you being attacked and the alarm falls from your hand, the alarm will immediately activate the extremely loud siren and flashing LED.

The alarm can also be activated by a trigger switch, and has a warning light to advise when the battery is low.



How to use:

This alarm has 3 settings which can be selected by moving the switch on the top of the alarm:

- A. Trigger Operation – Squeeze the trigger switch to activate the alarm and the flashing light.
- B. Alarm Off
- C. Trigger and sensor operation – The alarm and light activate if you squeeze the trigger or if the alarm is separated from you hand.

The alarm also has a handy belt clip and wrist strap to allow you to store it comfortably when you are in a non-dangerous situation and the alarm is not required.

How to change the battery:

- Undo the screw in the base of the alarm.
- Lift the base cover on to its hinge and replace the battery with a 9 volt alkaline battery.
- Please ensure the battery is inserted correctly as incorrect insertion will prevent the alarm from working and may damage the alarm.
- Close the base cover and re-tighten the screw.
- Always test the alarm after changing the batteries. The alarm will operate for up to 2 hours constant use with a fresh battery.

Warning:

- **The effectiveness of this alarm is due to its extremely loud and powerful siren, which produces 138 decibels of sound at source (125 decibels is the normal pain threshold of human hearing).**
- **As a result, prolonged exposure can cause permanent hearing damage.**
- **DO NOT ACTIVATE THE ALARM UNNECESSARILY**
- **Please take care to avoid endangering small children and pets.**
- **Walk the Walk and the manufacturer will not accept any responsibility for any loss, damage or personal injury sustained while in possession of this product whatever the cause or reason.**

Guarantee:

- The personal alarm is guaranteed against defects in materials and workmanship in normal use for a period of 1 year.
- This guarantee does not include the battery but is invalidated where a replacement battery has been incorrectly fitted.
- This guarantee is only valid if the alarm has not been altered, modified or repaired by anyone other than the manufacturer.